

YELLOW JACKET® Electronic Charging Scale



Updated circuit board now features “automatic-off” feature to preserve battery life

- With the old design (no automatic shut-off), we had complaints from people who left their scale on and came back to a dead battery. With the updated design, the scale shuts off after 15 minutes of no use. When you turn the scale back on, it starts up with all the previous settings, including the TARE value. After a short initialization period, the reading will be the same as if they had left the unit on the whole time.

Additional changes made with this redesign include:

- When used with the charging solenoid attachment, the new board “pulses” the solenoid as it gets close to the target charging weight. This improves the charging accuracy.
- Scales with the new board no longer have a screw for calibration. Calibration is now done using a special software mode via the keypad.

