



TITANMAX® FIRMWARE UPDATER FOR WINDOWS

NOTE: This update can be installed from a Windows 10 or Windows 11 PC (32-bit or 64-bit) or higher.

- STEP 1** In your web browser, go to the following link:
https://www.yellowjacket.com/downloads/windows/firmware/TITANMAX/TITANMAX_Updater.zip
- STEP 2** Download the **TITANMAX_Updater.zip** file.
- STEP 3** Unzip and extract the **TITANMAX_Updater.zip** folder to a safe location.
- STEP 4** Navigate to the **TITANMAX_Updater/TITANMAX_Driver** folder. Open **STM32Bootloader.bat - Shortcut**. (You will need admin access to download this driver.)




Note: If **STEP 4** fails, open the **DFU_Driver** folder, right-click **STM32Bootloader.bat**, and then select **Run as Administrator** from the drop-down menu.



- STEP 5** Ensure the TITANMAX® device is powered off. Locate the USB cable provided with the TITANMAX®, but do not plug it in yet.
- STEP 6** In the **TITANMAX_Updater** folder, open **TITANMAX_V01_XX_Updater.exe**.

STEP 7 At the **Update TITANMAX Software?** prompt, click **Yes**.



STEP 8 At the **Is this the device you want to program?** prompt, click **Yes**.




STEP 9 Press and hold the **Power** button. After 8 seconds, the LED will turn purple.

STEP 10 Plug the TITANMAX® into your computer using the USB cable included with your TITANMAX®.
Note: Make sure you are using the USB cable provided with your TITANMAX®. Some cables are for charging only and do not support data transfer.

STEP 11 Click **Update**.

TITANMAX Update Directions

- 1) Make sure the TITANMAX is powered OFF.
- 2) Press and hold the power button.
- 3) After about 8 seconds the LED will turn to purple.
- 4) Plug the TITANMAX into this computer using the provided USB cable.
- 5) Click the 'Update' button.
- 6) When the update is complete, disconnect the TITANMAX from the computer.
- 7) Access the TITANMAX general settings to confirm that the Firmware version is correct.



STEP 12 After the update has been installed, disconnect the TITANMAX® from the computer.

STEP 13 On the TITANMAX®, navigate to the **Settings (gear icon)** and confirm the firmware version (bottom-left) matches the latest version listed on the website.