## **OMNI**<sup>™</sup> Digital **Vacuum Gauge**



## **Operating Instructions:**

- 1. Press the ON/OFF button to power on the gauge.
- 2. To manually power off the gauge, press and hold the ON/OFF button until the screen displays the "YJ" logo.
- 3. To change a setting:
  - Tap the corresponding button to highlight the current setting.
  - Continue to tap this button until the desired value is displayed.
  - Press and hold this button to confirm the new setting. The highlighting will disappear when the setting has been confirmed.

**DISPLAY:** Select from several notification options. To change the background, press and hold for three seconds to inverse LCD mode.

**ON/OFF:** Power on and off, select from four different auto-off timer settings.

For best results, clean the sensor with mineral spirits.

