YELLOW JACKET®

SuperHeat/SubCool Calculator

with Thermometer and P/T Chart (69196



SuperHeat/SubCool measurements simplified, especially when converting systems to use some of the newer refrigerants

Simply choose the refrigerant you are working with, enter the pressure readings from your manifold gauges, clamp the thermocouple on the tube, then see the superheat/subcool reading in the display.

• Pre-programmed with 24 popular refrigerants:

R-22 R-32 R-134a R-290 R-404A R-407A R-407C R-407F R-408A R-409A R-410A R-414B R-417A R-421A R-422A R-422B R-422C R-422D R-427A R-434A R-437A R-438A R-441A R-507A

- Faster, more accurate pipe temperature measurements
- Clamp-on K-Type thermocouple for accurate temperature measurement
- Displays bubble, saturated and dew point temperatures
- Easy-to-use with the touch of a button
- Hold function keeps data on the LCD even when thermocouple is disconnected
- Package includes instrument, clamp temperature probe with 3' cord, battery and instruction manual



Specifications

Units of Measure: Temperature = ${}^{\circ}F$ or ${}^{\circ}C$;

Pressure = BAR, MPa,

kg/cm2 or PSI

Display Update: 0.5 seconds

Operating Temperature: Between 14 °F to 158 °F **Operating Humidity**: Between 10% to 90%

RH (non-condensing) Between 4 °F to 176 °F

Storage Temperature: Between 4 °F to 176 °F **PT Data Source**: NIST REFPROP Database

Accuracy: +/- 1.8 °F
Pressure Entry Range: 0 – 600 PSI
Battery Type/Life: 9V / 100 hours

Auto-Off Timing: 1 hour

UPC #	‡	Description
69196		SuperHeat/SubCool Calculator w/Thermometer and P/T Chart
69214		Replacement 1-3/8" Clamp Temperature Probe

Ritchie Engineering Company, Inc. YELLOW JACKET Products Division 10950 Hampshire Avenue South Bloomington, MN 55438-2623 USA Phone: (800)769-8370 or (952)943-1333 e-mail: custserv@yellowjacket.com www.yellowjacket.com

